

## Preparing the site for a Concrete Pump

In preparation for the arrival of our line pump you will need to provide **cement** to prime the pump line and a **washout container** for the disposal of waste concrete

- Please ensure you have cement on site to prime the pump before pouring. You will need 1 x 25kg bag of cement per 20 metres of pipeline.
- If you do not have cement available we can supply you with cement from one of our concrete lorries at a cost of £15 per 25kg. This will be added to your invoice after delivery if you choose to use this service.
- You will need to provide a large, waterproof container such as an old bathtub to wash out the pump line and hopper after use. It will be your responsibility to contain and dispose of any waste concrete as we cannot take this with us.
- **You will also need sufficient parking space in front of your property for both vehicles – approximately 6 standard parking spaces.**
- We strongly recommend that all surfaces surrounding the pump and pipeline, including roads, pavements, vehicles, buildings etc. are adequately protected from concrete spillages.
- We will endeavour to help clear up any waste concrete as part of our washdown procedure, however it is ultimately the hirers responsibility to ensure that the delivery area is washed down and waste concrete removed once we have left site.
- It is the hirer's responsibility for the safe environmental disposal of any excess concrete.